



**TREND MEDICAL**

## Application Guide for TREND PROLITE

MODEL # DCT-42U



Locate side wings: Measure patient and cut right and left to size.



Locate Back Panel



Lift back covering to expose side wing Velcro clamps.



Clamp cut side wings inside Velcro clamp on both left and right side.



Center brace on patients back



Wrap front wings around your waist and pull elastic straps to desired tension.

Trend Medical

[www.trend-med.com](http://www.trend-med.com)